


# Danville Signal Processing, Inc.

---

## dspstak™ c96k44



---

## User Manual

Version 1.00

# Danville Signal Processing, Inc.

## dspstak™ c96k44 User Manual

Copyright © 2004 Danville Signal Processing, Inc. All rights reserved. Printed in the USA.

Under the copyright laws, this manual may not be reproduced in any form without prior written permission from Danville Signal Processing, Inc.

Danville Signal Processing, Inc. strives to deliver the best product to our customers. As part of this goal, we are constantly trying to improve our products. Danville Signal Processing, Inc., therefore, reserves the right to make changes to product specification or documentation without prior notice. Updated operating manuals and product specification sheets are available at our website for downloading.

This manual may contain errors, omissions or “typo’s”. Please send your comments, suggestions and corrections to:

Danville Signal Processing, Inc.  
29687 82nd Avenue Way  
Cannon Falls, MN 55009

## Trademark Notice

dspstak is a trademark of Danville Signal Processing, Inc. VisualDSP++, and SHARC are trademarks of Analog Devices, Inc. CyberClocks is a trademark of Cypress Semiconductor Corporation.

## Contact Information

Danville Signal Processing, Inc.  
29687 82nd Avenue Way  
Cannon Falls, MN 55009

E-mail: [dsp@danvillesignal.com](mailto:dsp@danvillesignal.com)  
Web Site: <http://www.danvillesignal.com>

Voice: 507-263-5854  
Fax: 877-230-5629

# Table of Contents

<b>Overview .....</b>	<b>4</b>
Introducing dspstak™ .....	4
dspstak™ c96k44 .....	4
Introduction .....	5
<b>Hardware Description .....</b>	<b>6</b>
Wolfson WM8731 .....	6
Input Buffer Amplifier .....	7
Power Supply .....	7
Connectors .....	8
SPI Connector .....	9
Interconnect Port .....	10
<b>Operating Modes &amp; Register Configuration .....</b>	<b>12</b>
Serial Interface Configuration .....	12
Programmable Clocks .....	13
Operating Mode 0 .....	13
Operating Mode 1 .....	13
Operating Mode 2 .....	13
Codec Control Registers .....	14
<b>Software .....</b>	<b>15</b>
<b>Schematic .....</b>	<b>15</b>
<b>Mechanical Drawings .....</b>	<b>15</b>
<b>Accessories .....</b>	<b>15</b>
Power Amplifier Module .....	15
Extender Boards .....	16
<b>Product Warranty .....</b>	<b>17</b>

# Overview

DSP-based embedded applications often take the form of a digital signal processing engine coupled with a specialized data conversion and signal conditioning front end. The front end electronics and the DSP are almost always connected via high speed serial ports and the general purpose I/O ports of the DSP. In most cases, once the local memory and peripheral interfacing needs of the DSP are fulfilled, the DSP's data and address busses are no longer needed.

Standardized bus architectures such as PC/104, PCI and cPCI are all based on communicating via each board's data and address bus, while ignoring the needs of the most DSP / data conversion interfaces.

## Introducing dspstak™

Danville's dspstak modules are designed to simplify DSP-based embedded applications. Generally, each dspstak consists of two modules: a DSP Engine, and a signal conditioning/data conversion I/O Module. The Interconnect Port consists of SPORTs (high speed serial ports), SPI, general I/O, clocks and power connections.

DSP Engine modules generally consist of a DSP processor, memory, power supplies and standard digital I/O such as RS-232 and USB. We currently have products based on Analog Devices' SHARC® processors.

The I/O Modules may include signal conditioning electronics, A/D and/or D/A data converters, audio transceivers, unique connectors and a plethora of other special front end requirements. Since the I/O Module is separate from the DSP Engine Module, custom interfaces can be created quickly and inexpensively. Danville has a number of standard I/O Modules and often is willing to create a new one based on customer request. You can also create your own.

## **dspstak™ c96k44**

This manual covers the dspstak c96k44 I/O Module and is complemented by the dspstak Family Users Manual. The family manual covers topics that all dspstaks have in common. You will want to review the family manual for mechanical dimensions, system configurations, basic connector specifications, etc.

You will also need the relevant manuals and datasheets for the dspstak DSP Engine, the DSP processor and the data converter. Links to these manuals and other resources are found on our web site at [http://www.danvillesignal.com/index.php?id=dspdev\\_links](http://www.danvillesignal.com/index.php?id=dspdev_links)

# Intended Audience

The dspstak c96k44 is intended for DSP systems integrators, designers and programmers who may wish to integrate a dspstak into their products. This manual is primarily aimed at users who have a working knowledge of microcomputer technology and DSP related design. We assume that you are familiar with the Analog Devices DSP used on the companion dspstak DSP Engine.

# Introduction

The dspstak™ c96k44 is a 4 channel audio ADC & DAC I/O module based on a pair of sigma delta stereo audio codecs. Assuming a 12.288MHz master clock, the c96k44 allows sampling rates from 8k to 96k. Other sampling rates are available by reprogramming the dspstak DSP Engine to another master clock frequency. A special version of the c96k44 (opt 1) is available that allows two dspstak c96k44 modules to be combined for 8 channel configurations all with synchronous sampling.

There are a number of additional accessory boards available for the dspstak c96k44 as well. These include a small power amplifier module, BNC extender boards and 6.3mm phone jack extender boards.

The dspstak c96k44 includes the following items:

### Hardware:

- dspstak™ c96k44 board

### Documents & Programs (CD):

- This manual
- dspstak Family User Manual
- Device driver software

We recommend that you have the following tools and documents:

- Analog Devices VisualDSP++™ for SHARC®
- Wolfson WM8731 Data Sheet
- Documentation for the companion dspstak DSP Engine
- Cypress Semiconductor CyberClocks™

Our website ([www.danvillesignal.com](http://www.danvillesignal.com)) has downloads and links to other supplementary tools and documents.

# Hardware Description

The dspstak c96k44 I/O Module uses two Wolfson WM8731 codecs at its core. These codecs are 24 bit converters that can be used independently from each other to create two separate stereo channels (perhaps programmed to different sample rates) or they can be combined to sample coherently from the same clock. A variety of different sample rates are configurable under software control. Master clocks (MCLK1 & MCLK0) can be programmed to allow just about any sampling rate from 4k to 102.4k. A variety of sampling rate configurations are outlined later in this manual.

Each audio input is buffered by a low noise op amp stage. This op amp stage may be configured for low noise electret microphone circuits including mic bias.

The following sections expand on the basic hardware of the dspstak c96k44:

- Wolfson WM8731
- Input Buffer Amplifier
- Power Supply
- Connectors
- SPI Expansion

## Wolfson WM8731

The WM8731 has a variety of connections and configurations, most which are completely ignored by the c96k44. You may wish to look at the WM8731 datasheet block diagram while we discuss the WM8731 signal flow and configuration used by the dspstak c96k44.

Each audio input is routed to one of the two line inputs of the WM8731. This allows each channel to benefit from the built in PGA (programmable gain amplifier) available to the line inputs. Since the MICIN does not have a PGA, it is not used by the dspstak c96k44. Microphone support is accomplished by the Input Buffer Amplifier discussed in the next section.

Each input signal is converted by the internal ADC into 24 bit words that are transmitted in I2S format. Details on the data interface are in the next section of this manual.

Audio data is sent by the DSP to the DAC section of the codec. The HP outputs are used since these outputs have stepped attenuators available for level control. Since the line outputs do not have programmable attenuators, they are ignored.

The control port of the WM8731 is used to configure the sampling rates, PGAs, attenuators and other registers under software control. In the dspstak c96k44, these registers are all controlled by the dspstak SPI port using the #SPI\_SS chip select. Since as many as four WM8731 codecs can be

programmed from the same #SPI\_SS line, a special WM8731 address is used to activate each individual slave select line before the SPI port can write a codec. Codecs can be written individually or globally depending on the slave select mask. The software drivers included with the dspstak c96k44 illustrate the process. Details on the dspstak c96k44 operating modes and this special register are discussed later in this manual.

## Input Buffer Amplifier

A fixed gain amplifier buffers each audio input. This amplifier is configured with a gain of either 1 (0dB) or 11 (+20.8dB). The unity gain setting is generally used for line level signals since the internal PGA can be used to adjust the gain in 1.5dB steps. The +20.8dB setting is used for low level signals such as electret microphones. Signal levels should be restricted to +/- 1.4V full scale (1V rms sinusoid) .

If you are using typical electret microphones (two wire circuits), you can add a DC bias for each input by adding a shorting jumper to its corresponding Bias jumper location on JH3. Likewise, you can increase the gain of a channel by adding a shorting jumper to its Gain jumper location on JH3.

For example a shorting jumper on Gain3 and Bias3 will cause Input 3 to have an input gain of 20.8dB with microphone biasing. The other inputs would be configured as 0dB with no mic biasing.

The microphone bias supply (3V DC) without the typical 3K limiting resistor is also available on the connector pins adjacent to each audio input pin. This allows three wire microphone circuits to be supported as well as the more common two wire circuits.

Pin	Name	Open	Short
1&2	Gain – Audio In 3	0dB	+20.8dB
3&4	Mic Bias – Audio In 3	No	Yes
5&6	Gain – Audio In 2	0dB	+20.8dB
7&8	Mic Bias – Audio In 2	No	Yes
9&10	Gain – Audio In 1	0dB	+20.8dB
11&12	Mic Bias – Audio In 1	No	Yes
13&14	Gain – Audio In 0	0dB	+20.8dB
15&16	Mic Bias – Audio In 0	No	Yes

## Power Supply

The dspstak c96k44 derives its operating power from its companion dspstak DSP Engine. The dspstak c96k44 operates entirely on a single positive supply. We recommend a 9VDC supply for the dspstak when operating in a c96k44 + DSP Engine configuration. Higher supply voltages may

also be used with increased power dissipation since the analog 5 volt supply is derived using a linear regulator. There is no need for a negative or AC supply when using the dspstak c96k44 with a dspstak DSP Engine.

## Connectors

The primary connector on the c96k44 is JH1, a 34 pin latching dual row header (0.100 inch pitch). This allows a standard ribbon cable to interface to external input and output connections. JH1 is located on the side of the dspstak so that the DSP Engine connections can be mounted directly to a panel without interference. It is also low profile so that 1U 19 inch rack enclosures can be used as a possible enclosure.

In most applications, only connections on pins 15 through 34 are used. These are audio input and audio output connections with ground returns for each channel. Pins 1 through 14 are used for digital I/O connections and power supply fan out. Many of these connections are also available on the SPI expansion connector JH2. The dspstak c96k44 (Opt 1) uses a 20 pin latching dual row header instead of the 34 pin header used in the standard product. This connector is used exclusively for audio inputs and outputs. The Opt 1 version is used to create 8 channel systems and is always a companion to a standard dspstak c96k44 (3 board dspstak system).

The audio inputs and outputs may also be routed to an optional DB-37F connector located directly above the dspstak DSP Engine connectors. This allows the dspstak to be panel mounted with the audio connections available directly to the “outside” world. Unused pins on the DB-37F connector are brought out to pads that can be user defined by soldering wires directly to these pads.

JH1	JH1 Opt 1	J1	Name	Notes
1			DGND	
2			SPI SI	
3			#SPI SS1	IO5
4			#SPI SS2	IO6
5			SPI CLK	
6			SPI SO	
7			LED4	100 Ohm Series Resistor
8			LED3	237 Ohm Series Resistor
9			LED2	237 Ohm Series Resistor
10			LED1	237 Ohm Series Resistor
11			LED0	237 Ohm Series Resistor
12			Va+	Unregulated Positive Supply
13			Va-	Unregulated Negative Supply
14		11	AGND	
15	1	29	Audio Out 0	Left Ch U2



JH1	JH1 Opt 1	J1	Name	Notes
16	2	10	AGND	
17	3	28	Audio Out 1	Right Ch U2
18	4	9	AGND	
19	5	27	Audio Out 2	Left Ch U3
20	6	8	AGND	
21	7	26	Audio Out 3	Right Ch U3
22	8	7	AGND	
23	9	25	AGND	
24	10	6	Audio In 0	Left Ch U2
25	11	24	Mic Bias 0	
26	12	5	Mic Bias 1	
27	13	23	Audio In 1	Right Ch U2
28	14	4	AGND	
29	15	22	AGND	
30	16	3	Audio In 2	Left Ch U3
31	17	21	Mic Bias 2	
32	18	2	Mic Bias 3	
33	19	20	Audio In 3	Right Ch U3
34	20	1	AGND	

## SPI Connector

The dspstak c96k44 has a 10 pin 0.100 box header for digital I/O and SPI expansion. Do not drive long lines without buffers from this connector or the SPI interface may fail to operate correctly for local resources due to excessive capacitance loading.

Pin	Name	Notes
1	#RESET	
2	DGND	
3	#SPISS3	IO7
4	SPISO	MISO
5	#SPISS2	IO6
6	SPICLK	
7	SPISI	MOSI
8	#SPISS1	IO5
9	Vd+5	
10	Vd+3.3	

## Interconnect Port

The Interconnect Port is the only standard connection between the DSP Engine and I/O Modules. This port is described in detail in the dspstak Family Users Manual and the DSP Engine manuals.

Row	A&C	B	Name	C96k44	Notes
1	*	*	AGND		Analog Ground
2	*	*	Va+		Unregulated Positive Analog Supply
3	*	*	Va-	JH1 Only	Unregulated Negative Analog Supply
4	*	*	Va+5		Regulated Analog +5.0 Volt Supply
5	*	*	AGND		Analog Ground
6	*	*	Vd+5	JH2 Only	Digital 5.0 Volt Supply
7	*	*	Vd+3.3		Digital 3.3 Volt Supply
8	*	*	DGND		Digital Ground – Main Return
9	*		LED0	JH1 (237 R)	3.3V Digital Output
9		*	LED1	JH1 (237 R)	3.3V Digital Output
10	*		LED2	JH1 (237 R)	3.3V Digital Output
10		*	LED3	JH1 (237 R)	3.3V Digital Output
11	*		LED4	JH1 (100 R)	3.3V Digital Output
11		*	IO5 (#SPISS1)		(IO5 is alternate function with #SPISS1)
12	*		IO6 (#SPISS2)		(IO6 is alternate function with #SPISS2)
12		*	IO7 (#SPISS3)		(IO7 is alternate function with #SPISS3)
13	*		#SPI_SS	WM8731 SS	Primary SPI Slave Select
13		*	SPICLK		SPI Clock – DSP Engine is Master
14	*		SPISO		SPI Serial Out (MISO)
14		*	SPISI		SPI Serial In (MOSI)
15	*		IRQ		
15		*	#RESET	JH2 Only	
16	*		SYCLKIN	NC	External DSP Clock Input
16		*	SYCLKOUT	JH2 Only	Programmable clock
17	*		Vd+3.3		SPORT 0 – Full Duplex
17		*	GND		
18	*		DRA0	Mode 0,2	Audio Channels 1&2
18		*	DTA0	Mode 0,2	Audio Channels 1&2

Row	A&C	B	Name	C96k44	Notes
19	*		GND		
19		*	MCLK0	Mode 0,2	Audio Channels 1&2
20	*		RFS0	Mode 0,2	Audio Channels 1&2
20		*	TFS0	Mode 0,2	Audio Channels 1&2
21	*		RCLK0	Mode 0,2	Audio Channels 1&2
21		*	TCLK0	Mode 0,2	Audio Channels 1&2
22	*		#RESET0	NC	
22		*	GND		
23	*		DTB0	Mode 0	Audio Channels 3&4
23		*	DRB0	Mode 0	Audio Channels 3&4
24	*		GND		
24		*	Vd+3.3		
25	*		Vd+3.3		SPORT 1 – Full Duplex
25		*	GND		
26	*		DRA1	Mode 1 Mode 2	Audio Channels 1&2 Audio Channels 3&4
26		*	DTA1	Mode 1 Mode 2	Audio Channels 1&2 Audio Channels 3&4
27	*		GND		
27		*	MCLK1	Mode 1,2	Optional
28	*		RFS1		
28		*	TFS1		
29	*		RCLK1	Mode 2	Audio Channels 1&2
29		*	TCLK1	Mode 2	Audio Channels 1&2
30	*		#RESET1	NC	
30		*	GND		
31	*		DTB1	Mode 2	Audio Channels 3&4
31		*	DRB1	Mode 2	Audio Channels 3&4
32	*		GND		
32		*	Vd+3.3		

# Operating Modes & Register Configuration

The dspstak c96k44 has three different operating modes. The configuration jumpers on JH5 select the operating mode.

The primary codec, U2 is mapped to audio channels 0 and 1. The secondary codec, U3 is mapped to audio channels 2 and 3. Each codec is mapped to different SPORT connections depending on the operating mode.

U2 always uses MCLK0 as its master clock. U3 may use either MCLK0 or MCLK1 as its master clock. This choice is made via a shorting jumper on JH5.

Name	CFG1 Pins 3&4	CFG0 Pins 1&2	Notes:
Mode 0	Short	Short	U2 Master, U3 Slave
Mode 1	Short	Open	U2, U3 Slave (used by c96k44 – Opt 1)
Mode 2	Open	Short	U2 Master, U3 Master
Mode 3	Open	Open	Reserved

Name	MCLK1 Pins 5&6	MCLK0 Pins 9&10	Notes:
ILLEGAL!	Short	Short	Will Short Clocks!
MCLK1 Select	Short	Open	U3 uses MCLK1 – Use only with Mode 2
MCLK0 Select	Open	Short	U3 uses MCLK0
ILLEGAL!	Open	Open	Codecs won't operate!

Pins 7&8 of JH5 are ignored. They are connected to GND.

## Serial Interface Configuration

The dspstak c96k44 uses I2S interfacing for its audio data interface. In all cases, at least one codec acts as an I2S master. The DSP is always configured as an I2S slave. Although the WM8731 supports a variety of different audio data interfaces, for the purposes of the dspstak c96k44, the interface transmits and receives 32 bit words for each channel. Unused bits are generally padded with zeros.

The WM8731 registers must be configured correctly depending on the desired Operating Mode. The software drivers supplied with the c96k44 will help you with these settings.

# Programmable Clocks

Although a codec is always the I2S master, the master clock (MCLK0 or MCLK1) is always provided by the programmable clock on the dspstak DSP Engine. These clocks are very flexible and may be set to just about any desired clock for your application. Consult the dspstak DSP Engine manual to reconfigure these clocks for your application.

## Operating Mode 0

Operating Mode 0 uses only one full duplex SPORT. This SPORT is called SPORT0 on the dspstak Interconnect Port but is likely to be derived from two half duplex SPORTs in the DSP. Audio channels 0&1 (U2) are mapped to the DRA0 and DTA0 lines and audio channels 2&3 (U3) are mapped to the DRB0 and DTB0 lines.

All channels sample at the same time and must be set to the same sampling rate. The primary codec U2 acts as the I2S master. All timing is derived from U2, therefore U3 must be configured as an I2S slave. MCLK0 should be selected for U3.

## Operating Mode 1

Operating Mode 1 is a companion mode to Mode 0. Like Mode 0, it also uses only one full duplex SPORT, but in this case: SPORT1. Mode 1 is normally used with a dspstak c96k44 Opt 1. The Option 1 board differs from the standard dspstak c96k44 in that it has a special male/female stacking DIN connector for the Interconnect Port. This allows the c96k44 to be used in a three board dspstak configuration, two dspstak c96k44s (Std & Opt 1), and a dspstak DSP Engine. This creates an eight channel system.

Mode 1 always assumes that there is another dspstak c96k44 board operating in Mode 0. The "Mode 0" dspstak c96k44 acts as the I2S master (via its primary codec, U2). Both codecs on the "Mode 1" dspstak are I2S slaves.

Audio channels 0&1 (U2) are mapped to the DRA1 and DTA1 lines and audio channels 2&3 (U3) are mapped to the DRB1 and DTB1 lines.

All channels sample at the same time and must be set to the same sampling rate. This includes the other dspstak c96k44 operating in Mode 0. MCLK0 should be selected for U3.

## Operating Mode 2

Operating Mode 0 uses two full duplex SPORTs. These SPORTs are called SPORT0 and SPORT1 on the dspstak Interconnect Port but are likely to be derived from four half duplex SPORTs in the

DSP. Audio channels 0&1 (U2) are mapped to the DRA0 and DTA0 lines and audio channels 2&3 (U3) are mapped to the DRA1 and DTA1 lines.

In Mode 2, each codec is configured independently as an I2S master. This allows each codec to operate completely independently. You can have different sample rates for each codec. You can also program MCLK1 to be used as the master clock for U3. This means that you can have very different sample rates for each codec. For example, if MCLK1 is set to 19.6608MHz and MCLK0 is set to 18.432 MHz, you could be sampling channels 0&1 at 96k and channels 2&3 at 102.4k.

## Codec Control Registers

Each WM8731 codec is configured via SPI. It is a write-only interface that is used to set the sampling rate, configure the codec for the correct data interface, and adjust gain, attenuation and other operating parameters. These registers are described in the WM8731 datasheet and implemented in the dspstak c96k44 device drivers and example code.

The dspstak c96k44 maps all the control ports to a single SPI SS line. This creates a problem since there can be as many as four codecs in a c96k44 configuration and you don't necessarily want to write all the devices with the same data.

This situation was solved on the dspstak c96k44 by creating a new command on the WM8731. WM8731 commands are always at addresses less than 0x8000. In other words, Bit 15 is always 0. We take advantage of this situation by creating a new command at address 0x8000 (This would correspond to register (80h) in Wolfson documentation). The WM8731 ignores a command with this address.

Command 0x8000 is used to set the individual SPI SS lines on each codec. Bits 0 through 3 are used for this purpose where 1 is true.

- Bit 0 – Select the primary codec (U2) mapped to Sport 0
- Bit 1 – Select the secondary codec (U3) mapped to Sport 0
- Bit 2 – Select the primary codec (U2) mapped to Sport 1
- Bit 3 – Select the secondary codec (U3) mapped to Sport 1

This translates as follows:

- Bit 0 & Bit 1 select U2 & U3 respectively in Mode 0
- Bit 2 & Bit 3 select U2 & U3 respectively in Mode 1
- Bit 0 & Bit 3 select U2 & U3 respectively in Mode 2

The SPI\_SS line must be active (low) to select any codec regardless of the state of the 0x8000 register.

# Software

The Distribution CD includes software examples and device drivers that simplify the configuration of the dspstak c96k44. You may use these examples as take off points to start your own applications.

Our software library is constantly expanding. This code and other resources are available to our customers through our web site. Send an email to [support@danvillesignal.com](mailto:support@danvillesignal.com) to gain access to the customer section of our web site.

# Schematic

The Distribution CD includes a schematic diagram of the dspstak c96k44 in file sch\_c96k44.pdf

# Mechanical Drawings

Mechanical Drawings are included in the dspstak Family Users Manual. If you any need additional information on board mounting, clearances, etc, send an email to [support@danvillesignal.com](mailto:support@danvillesignal.com).

The dspstak can be incorporated into products in a variety of different ways. If you want to use the dspstak in an unusual configuration, you may want to check with us for suggestions, design review, etc.

# Accessories


The following accessories are available for the dspstak c96k44:

- dspstak c96k44 – BNC Extender
- dspstak c96k44 – 6.3mm Phone Jack Extender
- dspstak c96k44 – Power Amplifier

# Power Amplifier Module

A stereo power amplifier module is available that plugs into unused connectors on the dspstak c96k44. Since the power amplifier can draw significant current, the dspstak Engine may need to be modified with higher current rectifiers as well. Check with Danville if you are interested .

## Extender Boards



Each extender board is designed to expand the latching header into 8 separate connectors. In the BNC case, the three wire microphone bias circuit is not available. The 6.3mm (1/4") phone jack version can supply the microphone bias on the ring if desired. The extender boards do not connect to the optional digital I/O, only the audio inputs and outputs are used.

In the standard version, a 20 pin right angle female dual row header connects directly to the latching header. The extender boards can also be supplied with a 20 pin latching header. This would also require a ribbon cable (34 pin to 20 pin for standard c96k44 boards) to connect the boards.

The extender boards can also be assembled to use a mating DB-37M connector. All variations of the extender board are the same price.



# Product Warranty

Danville Signal Processing, Inc. products carry the following warranty:

Danville Signal Processing products are warranted against defects in materials and workmanship. If Danville Signal Processing receives notice of such defects during the warranty period, Danville Signal Processing shall, at its option, either repair or replace hardware products, which prove to be defective.

Danville Signal Processing software and firmware products, which are designated by Danville Signal Processing for use with our hardware products, are warranted not to fail to execute their programming instructions due to defects in materials and workmanship. If Danville Signal Processing receives notice of such defects during the warranty period, Danville Signal Processing shall, at its option, either repair or replace software media or firmware, which do not execute their programming instructions due to such defects. Danville Signal Processing does not warrant that operation of the software, firmware, or hardware shall be uninterrupted or error free.

The warranty period for each product is one year from date of installation.

## **Limitation of Warranty:**

The forgoing warranty shall not apply to defects resulting from:

- Improper or inadequate maintenance by the Buyer;
- Buyer-supplied software or interfacing;
- Unauthorized modification or misuse;
- Operation outside the environmental specification of the product;
- Improper site preparation and maintenance.

## **Exclusive Remedies:**

The remedies provided herein are the Buyer's sole and exclusive remedies. In no event shall Danville Signal Processing, Inc. be liable for direct, indirect, special, incidental or consequential damages (including loss of profits) whether based on contract, tort, or any other legal theory.